





Chuck controller required additionally

Fig. 1



(The above figure shows 3 standard units connected.)




[Application]

This model is used with grinders of wood slice cutters and most suitable for angle grinding of edges. It can also be applied to uniform grinding in the longitudinal direction.

- •As a connecting type, this model consists of a main unit, lead shaft, intermediate shaft, tilting shaft, tilting base and intermediate tilting base. When one unit is used, it is used as shown in Fig. 2 and when three units are used, they are connected as shown in Fig. 1.
- As the tilting torque is large, the shaft has been made long to increase the reduction ratio on your machine side. (The scaled ring and tilting device are not included. Provide them on your machine side.)
- The chuck-to-chuck connecting clearance is as small as 40 mm.

(When ordering)

If you want to connect units as shown in Fig. 1, please order the number of main units to be connected.



[mm (in)]

Model	Nominal Dimensions	Top Plate		Pole pitch	Length	Voltage	Current	Mass	Electro	Remarks
		L ₁	Le	P	L2	VOILAGE	Current	IVIASS	Chuck Master	nemarks
KET-20100UTS	200 (7.87) × 1000 (39.3)	1000 (39.3)	920 (36.2)	28(4+24) (1.10) **Pitch varies according to places.	1340 (52.7)	90 VDC	0.72A	Approx.305kg/ 672 lb	ES-M103B ES-M305B EH-V105D EH-V205D EH-VE105D EH-VE205D	**For models with a combination of a rectifier and demagnetizer, see pages of "Chuck Controllers."
KET-20120UTS	200 (7.87) × 1200 (47.2)	1200 (47.2)	1120 (44.0)		1540 (60.6)		0.90A	Approx.355kg/ 782 lb		
KET-20140UTS	200 (7.87) × 1400 (55.1)	1400 (55.1)	1320 (51.9)		1740 (68.5)		1.00A	Approx.400kg/ 881 lb		
KET-20150UTS	200 (7.87) × 1500 (59.0)	1500 (59.0)	1420 (55.9)		1840(72.4)		1.25A	Approx.430kg/ 948 lb		
KET-20160UTJS	200 (7.87) × 1600 (62.9)	1600 (62.9)	1520 (59.8)		1940 (76.3)		1.35A	Approx.445kg/ 981 lb		
KET-20170UTJS	200 (7.87) × 1700 (66.9)	1700 (66.9)	1620 (63.7)		2040 (80.3)		1.33A	Approx.465kg/1025 lb		

*The chuck controllers in this table are for single unit and when two or more units are connected, use "current x number of units connected" to select a suitable model

*If the magnetic force needs not be adjusted, use ES-M. *The chuck controller and clamp parts are not included. The KANETEC chucks work best when a KANETEC chuck controller is used.

*The above models include the main unit, right/left tilting bases, lead shaft and tilting shaft.